


Power and Signal Modules – Field assembly



	Han® 300A PE module	Han® 200 A Axial module	Han® 200 A PE module	Han® 100 A Axial module	Han® PE module
100 - 300 A	 1 x PE* 300 A Axial screw termination	 1 contact* 200 A / 1000 V Axial screw termination	 1 x PE* 200 A Axial screw termination	 2 contacts* 100 A / 1000 V Axial screw termination	 1 x PE 100 A Axial screw termination
	95 ... 120 mm²	40 ... 70 mm²	40 ... 70 mm²	16 ... 35 mm²	16 ... 35 mm²
	(M) 09 14 001 2681	09 14 001 2662	09 14 001 2667	09 14 002 2651	09 14 001 2633
	(F) 09 14 001 2781	09 14 001 2762	09 14 001 2767	09 14 002 2751	09 14 001 2733
		25 ... 40 mm²	25 ... 40 mm²	10 ... 25 mm²	10 ... 25 mm²
	(M)	09 14 001 2663	09 14 001 2668	09 14 002 2653	09 14 001 2632
	(F)	09 14 001 2763	09 14 001 2768	09 14 002 2753	09 14 001 2732
	Han® 70 A Axial module	Han® 40A Axial module	Han® C Axial module	Han® C Push-In module	Han® CC Push-In module
40 - 70 A	 2 contacts 70 A / 1000 V Axial screw termination	 2 contacts 40 A / 1000 V Axial screw termination	 3 contacts 40 A / 690 V Axial screw termination	 3 contacts 40 A / 690V Push-In termination	 4 contacts 40 A / 690V Push-In termination
	14 ... 22 mm²	6 ... 10 mm²	6 ... 10 mm²	1.5 ... 6 mm²	1.5 ... 6 mm²
	(M) 09 14 002 2647	09 14 002 2602	09 14 003 2602	09 14 003 5001	09 14 004 5001
	(F) 09 14 002 2742	09 14 002 2702	09 14 003 2702	09 14 003 5101	09 14 004 5101
		6 ... 16 mm²	2.5 ... 8 mm²		
	(M) 09 14 002 2646	09 14 002 2601	09 14 003 2601		
	(F) 09 14 002 2741	09 14 002 2701	09 14 003 2701		
	Han® ES module	Han E® screw module	Han E® Push-In module	Han EE® Push-In module	Han DD® Push-In module
10 - 16 A	 5 contacts 16 A / 400 V Cage clamp termination 0.14 ... 2.5 mm	 5 contacts 16 A / 230/400 V Screw termination 0.5 ... 2.5 mm²	 6 contacts 16 A / 500V Push-In termination 0.5 ... 2.5 mm²	 8 contacts 16 A / 400V Push-In termination 0.5 ... 2.5 mm²	 12 contacts 10 A / 250V Push-In termination 0.14 ... 1.5 mm²
	(M) 09 14 005 2616	09 14 005 2601	09 14 006 5001	09 14 008 5001	09 14 012 5001
	(F) 09 14 005 2716	09 14 005 2701	09 14 006 5101	09 14 008 5101	09 14 012 5101

Pneumatic Modules



	Pneumatic module	Contacts (≤ 10 bar)			Module
3 - 6 mm Tubes					Number of contacts: 3 
	For tube diameter Ø	6 mm OD	4 mm OD	3 mm OD	Male module (M) 09 14 003 3501
	Male contact	09 14 000 6356	09 14 000 6354	09 14 000 6353	Female module (F) 09 14 003 3501
	Female without shut-off	09 14 000 6456	09 14 000 6454	09 14 000 6453	
	Female with shut-off	09 14 000 6466	09 14 000 6464	09 14 000 6463	
	Pneumatic double module	Contacts (≤ 10 bar)			Module
8 + 10 mm Tubes					Number of contacts: 2* 
	For tube diameter Ø	8 mm OD	10 mm OD	10 mm ID	Male module (M) 09 14 002 3501
	Male contact	09 14 000 6358	09 14 000 6350	09 14 000 6310	Female module (F) 09 14 002 3502
	Female without shut-off	09 14 000 6458	09 14 000 6450	09 14 000 6410	
	Female with shut-off	09 14 000 6468	09 14 000 6460	09 14 000 6411	

(M) = Part numbers Male Module (F) = Part numbers Female Module * Double module, requires two places in the frame